

The CS004a –Safety Film/Strap Cutter

Thank you for choosing the CS004a Safety film/strap cutter, the CS004a has been designed to provide user cut protection through an enclosed blade. Although a disposable (no blade changing) product, used correctly it should provide an extensive life. Detailed below are some simple measures which will help keep the user safe and achieve the best life from the knife.


User Information/Instruction Sheet

- The knife is designed to cut Films (such as Shrink Wrap, Bubble Wrap, Cellophane) and Plastic Strapping.
- Never dismantle or modify the knife, it has been designed to have no maintenance, any dismantling or modification could lead to sharp blades damaging people and or products and contamination of products.
- Never cut towards yourself – always cut away from the body considering others in the area.
- Never use the knife to cut materials that it has not been designed for.
- Never use the knife as a lever, it is a cutting device.
- Always report any damage to the knife and replace it immediately.
- Always change the knife when the blade become blunt (a blunt blade requires more effort, slows the operation and increases the likelihood of accidents).
- Always let the blade do the work, positioned correctly a sharp blade will cut with ease; applying large effort will damage the knife and product as well as lead to more accidents.

Knife Operation

Tape Cutting/Scoring

The small serrated fixed blade at the tip of the beak is designed to cut /score packing tape.



Film/Strap Cutting

The enclosed beak blade is designed to cut film and strapping (The finger guard also acts as an angle guide for the blade).

