



Innovation at the right price

User information sheet ERG 177



I) Principle use

<p>Slide the slider to deploy the blade.</p>	
<p>During the cut ensure the slider is released (the blade is kept deployed by friction of the material being cut).</p>	
<p>Thus when exiting the material (as the slider is not held out) the blade automatically retracts safely.</p>	

+ For greater safety: Discover our accessories

ERGBH01: Cordoflex Belt Holster
Clips to the belt or the belt loops through.



Do not lose your safety knife !

Sharps Bins - Safely dispose of used blades



Innovation at the right price







User information sheet

ERG 177

II) Main applications

 <p>★★★★</p>	 <p>Simple Cannelure</p> <p>★★★★</p>	 <p>Double Cannelure</p> <p>★★★★</p>	 <p>Triple Cannelure</p> <p>★★★</p>
<p>Corrugated packing...</p>	<p>Simple corrugated cardboard 4mm thick.</p>	<p>Double fluted cardboard up to 8mm thick.</p>	<p>Cardboard Triple grooves up to 12/15mm thick</p>
	 <p>★</p>	 <p>★</p>	 <p>★★★</p>
	<p>Straps, plastic foils composites, textiles .</p>	<p>Stretch film thickness up to 30µm .</p>	<p>Simple cardboard up to 2mm thick.</p>

III) Changing the blade

<p>1</p>  <p>Unscrew the flat head screw at the top of the metal head</p>	<p>2</p>  <p>Swing open the head and operate the slider to remove the blade</p>	<p>3</p>  <p>Take a new blade from the reserve</p>
<p>4</p>  <p>Position the new blade and close the head</p>	<p>5</p>  <p>Secure the flat head screws at the top of the metal head</p>	<p>6</p>  <p>Your knife is ready to use!</p>