



ERG 2010

Innovation at the right price

User information sheet ERG 2010 / ERG 2070 Series





I) Principle use

Slide the slider to deploy the blade.



During the cut ensure the slider is released (the blade is kept deployed by friction of the material being cut).



Thus when exiting the material (as the slider is not held out) the blade automatically retracts safely.







ERG 2010 ERG 2070

Innovation at the right price


User information sheet

ERG 2010 / ERG 2070 Series


II) Changing the blade

These safety knives are ambidextrous:

The knives can be used by right & left-handed users (Invert the blade for left hand use)



III) Main applications







ERG 2010

Innovation at the right price

User information sheet ERG 2010 / ERG 2070 Series

IV) Setting the output length of blade



Personalise your ERG 2010 / ERG 2070 by choosing your Slider and your maximum length of blade!

ERG 2010:



Indexer with all 4 notches maximum blade length = 4 mm



3 notches = 8mm



2 notches = 12 mm



1 notches = 15 mm



Without Indexer = 16 mm

ERG 2070:



Indexer with all 4 notches maximum blade length = 14 mm



3 notches = 16mm



2 notches = 18 mm



1 notches = 20 mm



Without Indexer = 22 mm

G For greater safety: Discover our accessories

ERGBH01: Cordoflex Belt Holster Clips to the belt or the belt loops through.



Do not lose your safety knife!

Sharps Bins - Safely dispose of used blades



Accordant Safety Knives

G1 Roman Hill Business Park Broadmayne, Dorchester DT2 8LY Uk web: www.safetyknives.co.uk Tel: +44 (0)1305 251971

email: sales@safetyknives.co.uk Fax: +44 (0)1305 257552